

HVO Summit



Name

		Pass 1		Pass 2	
BUFFER	Mode :	Double		Double	
	Distance - Ft.	Forward	Reverse	Forward	Reverse
		<input type="text" value="38.0"/>	<input type="text" value="38.0"/>	<input type="text" value="27.0"/>	<input type="text" value="20.0"/>
OIL	Mode :	Double		Double	
	Distances - Ft.	Forward	Reverse	Forward	Reverse
	left outside :	<input type="text" value="25.0"/>	<input type="text" value="20.0"/>	<input type="text" value="7.0"/>	<input type="text" value="7.0"/>
	left track :	<input type="text" value="28.0"/>	<input type="text" value="23.0"/>	<input type="text" value="15.0"/>	<input type="text" value="12.0"/>
	left inside :	<input type="text" value="33.0"/>	<input type="text" value="33.0"/>	<input type="text" value="20.0"/>	<input type="text" value="20.0"/>
	right inside :	<input type="text" value="33.0"/>	<input type="text" value="33.0"/>	<input type="text" value="20.0"/>	<input type="text" value="20.0"/>
	right track :	<input type="text" value="28.0"/>	<input type="text" value="23.0"/>	<input type="text" value="15.0"/>	<input type="text" value="12.0"/>
	right outside :	<input type="text" value="25.0"/>	<input type="text" value="20.0"/>	<input type="text" value="7.0"/>	<input type="text" value="1.0"/>
	Transfer Rate %	<input type="text" value="40"/>	<input type="text" value="70"/>	<input type="text" value="75"/>	<input type="text" value="100"/>

Short Run	Mode	<input type="text" value="Off"/>
Turn-around Distance	<input type="text" value="0.0"/>	Ft.

Stripping	Mode	<input type="text" value="Full"/>
Start	<input type="text" value="0.0"/>	Ft.
Cleaner Pad Distance	<input type="text" value="61.5"/>	Ft.
Vacuum	<input type="text" value="On Start"/>	

Cleaner Flow	In oil	<input type="text" value="100"/>	%
	Back lane	<input type="text" value="20"/>	%

		Pass 1		Pass 2	
SPEED SETTINGS:	Travel	Forward	Reverse	Forward	Reverse
		Medium	Medium	Medium	Medium
	Condition	Medium	Medium	Medium	Medium
	Strip	Medium			

**Use #4 foams in center tanks,
 #6 in track tanks and #8 in outsides**