

HVO Summit



Name	Mexico City	
BUFFER	Mode :	Double
	Distance - Ft.	43.0
OIL	Mode :	Double
	Distances - Ft.	43.0
	left outside :	26.0
	left track :	30.0
	left inside :	36.0
	right inside :	36.0
	right track :	30.0
	right outside :	26.0
	Transfer Rate %	30
	SPEED SETTINGS:	Travel
Condition		Medium
Strip		Medium

Pass 1	Pass 2
Mode : Double	Mode : Double
Forward	Forward
Reverse	Reverse
43.0	30.0
43.0	16.0

Pass 1	Pass 2
Mode : Double	Mode : Double
Forward	Forward
Reverse	Reverse
26.0	18.0
20.0	10.0
30.0	18.0
28.0	12.0
36.0	23.0
33.0	15.0
36.0	23.0
33.0	15.0
30.0	18.0
28.0	12.0
26.0	18.0
20.0	10.0
30	90
70	100

Short Run	Mode	Off
Turn-around	Distance	0.0 Ft.
Stripping	Mode	Full
Start	Distance	0.0 Ft.
Cleaner Pad	Distance	61.5 Ft.
Vacuum		On Start
Cleaner Flow	In oil	100 %
	Back lane	25 %

Split the center tanks using #4 wicks on boards 20-16 and #5 on boards 15-10
 Use #6 wicks in tracks, and #8 in outsides