



Official Lane Maintenance and Capital Equipment Provider



ENVOY



AUTHORITY22

Select Machine

Pattern Information

Date:

Pattern Type: Sport

Pattern Difficulty: High

Pattern Designer: BRUNSWICK

Pattern Volume (ml): 26.88

Surface Information

Surface Type:

Surface Brand:

Age:

Pattern Parameters

Pattern Number:

Pattern Name: STOCKHOLM 18

Mode: Clean & Oil

Forward Speed: Max Clean

Start Cleaner Spray: 0

Start Squeegee: 0

Start Oiling: 6

Split Pattern: No

Supplies Information

Lane Cleaner:

Cleaner Mixture Ratio: : 1

Cleaner Transition Distance: 38 Authority22

Cleaner Spray End Distance: 53 Envoy

Lane Conditioner:

Notes WB Stockholm (36') 2018

Zone	1	2	3	4	5	6	7	8	Pattern Ratio by Volume
Zone End Distance	10	15	27	30	36				
Zone Ratio L	2.8 : 1	2.8 : 1	2.7 : 1	2.3 : 1	### : 1	### : 1	### : 1	### : 1	2.74 : 1
Zone Ratio R	2.0 : 1	2.0 : 1	1.9 : 1	1.6 : 1	### : 1	### : 1	### : 1	### : 1	2.02 : 1
Zone Volume (ml)	10.47	5.07	9.50	1.84	0.00	0.00	0.00	0.00	

ZONE	7 Pin Side														Board Number												10 Pin Side												
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1
1	9	9	18	18	27	41	50	59	75	75	87	87	87	87	87	87	87	87	87	87	87	87	87	87	87	87	87	87	87	75	75	63	59	41	27	18	9	9	
2	8	8	17	17	26	40	49	58	74	74	84	84	84	84	84	84	84	84	84	84	84	84	84	84	84	84	84	84	84	74	74	62	58	40	26	17	8	8	
3	7	7	14	14	21	32	39	46	58	58	65	65	65	65	65	65	65	65	65	65	65	65	65	65	65	65	65	65	65	58	58	50	46	32	21	14	7	7	
4	5	5	12	12	18	28	34	41	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48	48
5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
6																																							
7																																							
8																																							

